

SCK GND

3V8 TP40 PWDN

SDA0 TP46


SCL0 TP47 Cam_VDD



SD_VDD TP49


SD_2_0

USB_ON/OFF



CLK2 DAT2

SIM2




RST2 VDD2


SIM1

- D2
- R18
- D3
- R19
- D7
- D4
- R20
- D5
- R21
- R22
- D6
- Q3
- Q2
- Q1
- C3

- TP8
- TP22
- TP12
- TP11
- TP10
- VDD
- DAT
- CLK
- RST



- DAT2
- DAT1
- DAT3
- CLK
- CMD
- VDD



U16

